

FAMILIARICESE CON SU DESARRUGADOR DE PRENDAS

IMPORTANT damaged cord or plug, if it is not working **SAFETY** properly, or if it has been dropped or damaged, or dropped into water. Do not attempt to repair **INSTRUCTIONS** the appliance. Incorrect reassembly or repair could cause a risk of fire, electric shock, or injury to persons when the appliance is used. Return the appliance to an authorized service

> 5. Keep the cord away from heated surfaces. Do not allow cord to contact heated surfaces. Do not pull or twist cord. Let appliance cool completely before putting away. Loop cord loosely around appliance when storing.

center for examination and repair.

6. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.

7. To reduce likelihood of circuit overload, do not operate another high wattage appliance on the same circuit.

8. Use of an extension cord is not recommended. If an extension cord is absolutely necessary, a 15-ampere-rated cord should be used. Cords rated for less amperage may overheat. Care should be taken to arrange the cord so that it cannot be pulled or tripped over.

9. Use caution when changing attachments. Please be sure the unit is off and no steam is being released to avoid contact with hot

10. Use caution when changing attachments as they may contain hot water from condensation. T-nozzle should never be placed on the unit when in use or when pre-heating. Ensure the attachments are dry or cooled off to avoid contact with hot water.

11. Do not hold steamer during use. Steamer must sit on floor while steaming.

for storage.

13. Use caution when removing hose cap. Remove slowly. damaged.

UNPACKING INSTRUCTIONS

Place the box on a large sturdy flat surface. Carefully remove the appliance from the packing material. Keep all plastic bags away from children.

INDUSTRIAL USE

is podnilis en is puerta

Nest el gancho para colgar

provocar quemaduras. No LLENE EL DEPOSITO

EL DEPOSITO. Esto podría causar un derrame y

Dasarse, de la linea "Max Fill". No sobrellene

DE OPERACION

INSTRUCCIONES

Desbués de usarla, se relajara y la boquilla

qe turno en sentido antihorario y âlcela.

Puede que la manguera esté rigida al principio.

Gire la extremidad de la manguera un cuarto

(bermita que el aparato entrie antes de

con agua corriente hasta el nivel deseado, sin

Saque la tapa del depósito y llene el depósito

(OTARAGA JE RATOENOO EU SETNA)

OTISOABO DEL DEPÓSITO

eucajara en el gancno.

desconectar la manguera)

Como desconectar la manguera

CON AGUA CALIENTE.

STEAMER ASSEMBLY

Attaching the Steamer Hose

Align the 2 protrusions in hose cap with the 2 openings in the steamer housing. Push down and twist clockwise (about one quarter turn) to securely fasten hose onto housing.



is manguera en el oriticio y gire un cuarto de nendiauras en el ornicio del deposito, inserte ia extremidad de la manguera con las Haga coincidir las dos protuberancias en Como conectar la manguera

ENSAMBLADO

ı. insertar.

sicance de los ninos. Mantenga las tundas de plastico tuera del sednus y saque el aparato cuidadosamente. Ponga la caja sobre una superficie llana y DESEMPACADO

turno en sentido horario para sujetarla.

NO DISENADO PARA USO COMERCIAL PARA USO DOMESTICO SOLAMENTE

INSTRUCCIONES **GUARDE ESTAS**

nembo promingado. durante el uso. Evite tocarla durante un 11. La manguera se vuelve muy caliente bnesto dne contieue agua caliente.

10. Jenga cuidado al desplazar el aparato, puede contener agua canente.

lenga cuidado al vaciar el tanque, puesto que

Removing the Steamer Hose

To remove, turn counterclockwise one quarter turn, then gently pull up until

Hose may be stiff upon removal from box. Hose will relax after initial use. T-handle will sit properly on door hook once hose is relaxed.

OPERATING INSTRUCTIONS

Remove the hose cap. Fill the reservoir with clean tap water to the desired level or until water reaches "Max Fill" line on side of unit. DO NOT OVERFILL as this will cause water to boil out of steamer and spill. Empty until water is just under the internal fill indicator, DO NOT



csilente y el vapor pueden causar heridas. bnesto dne boquian estar calientes o contener 9. Las partes de metal calientes, el agua 10. Cambie los accesorios con cuidado, aparato. Cójalo por la clavija. 8. Nunca jale el cable para desconectar el

eu el dancho antes de encender el aparato.

alguien las tenga puestas.

seguridad.

V. Extienda la manguera y cueigue la boquilla

6. Nunca desarrugue prendas mientras

Este aparato produce vapor muy caliente.

este conectado. Mantengala alejada del cable

mientras este caliente o mientras el aparato

4. No colodue la boquilla en ninguna superricie

uiudnus de las aberturas o en la manguera.

3. Nunca deje caer ni inserte un objeto en

electricista. No intente vencer esta funcion de

entrara completamente, comuniquese con un

en el tomacornente, invierteia. Si aun no

manera en el tomacorriente. Si no entrara

sednuaga, se podra encnurar de una soia

más ancha que otra). Como medida de

qe nus cısvıls bojsuzsags (nus bats es

7. El cable de este aparato esta dotado

1. Nunca deje este aparato desatendido

12. Permita que el aparato enfrie antes de

desbués de encenderse. No lo alce durante

11. El aparato debe permanecer en el piso

podnijis sopre el aparato cuando el aparato

Trios artes de manipularios. Nunca ponga ia

agua caliente. Asegurese que esten secos y

1000-watt heater

high-velocity steam

Power switch

6' nower cord

Cool-touch

for professional

13. Abra el tanque con mucho culdado.

esté calentando o funcionando.

mientras este conectado.

PRECAUCION

vaciar el tanque.

Fixed T-nozzle with

high-velocity steam jets

Easy-carry handle

.osu 19

GETTING TO KNOW YOUR STEAMER

NUNCA TOQUE LA BOQUINA GULANTE EL USO.

eléctrico. Utilice el gancho provisto.

y que no este emitiendo vapor antes de 9. Asegurese que el aparato este apagado usque lo pueda Jalar o tropezar.

soprecalentar. Ubique el cable de manera que extensión de menor capacidad podría extensión de 15 amperios, porque una ei aparato con una extension, utilice una 8. Aunque no es aconsejable, si debe usar mismo circuito.

obece uiudnu otro aparato de alto vataje en el /. Para prevenir las sobrecargas electricas, no

serosol (spray) o donde se esté administrando Inucionar donde se esten usando productos en e. No lo utilice en exteriores, ni lo haga antes de almacenario.

Permita que el aparato enfrie completamente eutoliado del cable para guardarlo en la base. alrededor del aparato. Oprima el pedal de calientes. No Jale, retuerza ni enrolle el cable 5. Mantenga el cable alejado de las superficies bara que lo examinen y lo reparen.

el aparato a un centro de servicio autorizado ае поселаю, егестосистоп у пелааз, кедгезе de manera incorrecta aumenta los riesgos reparar el aparato. El ensamblar las partes danado o si hubiese caido al agua. No intente collectamente, si nubiese caido, si estuviese clavija estuviesen danados, si no funcionase 4. Nunca utilice el aparato si el cable o la

accesorios recomendados por el fabricante. solamente segun las instrucciones. Solo use ei broposito para ei cuai tue disenado y 3. Utilice este aparato unicamente con

zopre o cerca de ninos o personas con alguna cambiar los accesorios.

5. Este aparato no deberia ser utilizado por, oodria rebosar y provocar quemaduras. 1. No sobrellene el tanque. El agua caliente incendio o heridas:

eqneir el riesgo de quemaduras, electrocución, ADVERTENCIA — Para

nmediatamente. No toque el agua. 4. Si el aparato cayera al agua, desconectelo

agua u otro liquido. 3. No colodue el aparato ni lo deje caer al un lavabo.

onega caer o ser empujado a una banera o 2. No coloque ni guarde el aparato donde inmediatamente después de usarlo. l. Siempre desconecte el aparato

jesão de muerte o herida por descarga: ei interruptor este apagado. Para reducir ei euchufado permanece bajo tensión, aunque PELIGRO — Cualquier aparato

DE USARLO INSTRUCCIONES ANTES LEA TODAS LAS

eulle las cuales las siguientes: romar precauciones básicas de seguridad, esbecisimente en la presencia de ninos, debe Siempre que use aparatos electricos,

IMPORTANTES SEGURIDAD MEDIDAS DE

OPERATING THE STEAMER

- 1. Over the door hanger: hang this over the top of your door and use to hang the T-nozzle and any garment on hanger. (Overloading may cause deformation of door hook.)
- 2. Make sure the ON/OFF switch is in the OFF position.
- 3. Make sure all hose connections are secure and tight.
- 4. Hang the T-nozzle on the door hook. 5. Plug the cord into a normal electrical
- outlet. 6. Turn the ON/OFF switch to the
- ON position. 7. The switch will light to indicate when
- power is on. 8. Steam will be produced from the
- nozzle in about four to five minutes. Be sure to keep T-nozzle on the door hook while heating up.
- 9. To turn steamer off, press ON/OFF switch to the OFF position.

Over-the-doo

4. Never operate this appliance if it has a

When using electrical appliances, especially when children are present, basic safety precautions should always be taken, including the following:

READ ALL INSTRUCTIONS BEFORE USING

DANGER — Any appliance is

electrically live even when the switch is off. To reduce the risk of death by electric shock: 1. Always unplug appliance immediately

after using. 2. Do not place or store appliance where it can fall or be pulled into a tub or sink.

3. Do not place in, or drop into water or other 4. If an appliance falls into water, unplug it immediately. Do not reach into the water.

WARNING — To reduce the risk of burns, electrocution, fire, or injury to persons: 1. Do not overfill steamer as it can cause hot water to boil out and burn.

2. This appliance should not be used by or near children or individuals with certain disabilities. 3. Use this appliance only for its intended

use as described in this manual. Do not use attachments not recommended by the manufacturer.

12. Allow unit to cool before emptying reservoir

14. Do not use if unit has been dropped or

CAUTION

1. This appliance should never be left unattended when plugged in.

2. This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

3. Never drop or insert any object into any

4. Do not place the steam nozzle directly on any surface or on the appliance power cord while it is hot or plugged in. Use the door hook provided.

5. This product emits hot steam during use. Do not touch T-nozzle when product is in use.

6. Do not steam garments while on a person. 7. Before unit is turned on the hose must be extended and hanging on door hook.

8. Never vank cord to disconnect from outlet. Instead, grasp plug and pull to disconnect.

9. Burns could occur from touching hot metal parts, hot water, or steam. Use care when you turn a steam appliance upside down - there may be hot water in reservoir.

10. Use caution when carrying steamer as it contains hot water

11. Caution: hose will be hot when in use. Avoid prolonged contact.

SAVE THESE (make sure unit has cooled) **INSTRUCTIONS**

FOR HOUSEHOLD USE ONLY hose releases. NOT FOR COMMERCIAL OR

> FILLING THE WATER RESERVOIR (PRIOR TO PLUGGING IN THE APPLIANCE)

FILL THE CONTAINER WITH HOT WATER.



Hanging the t-nozzle on the door hook

desarrugador

IB-8811

East Windsor, NJ 08520/Glendale, Az 85307 ©2008 Conair Corporation

http://www.conair.com

Conair, Ilame al 1-800-3-CONAIR o visite Para más información sobre los productos de

> Glendale, AZ 85307 7475 N. Glen Harbor Blvd. Dervice Department Corporation Centro de Servicio

F8E0 FA480

varian de un Estado a otro. citicos y usted puede tener otros derecnos que Esta garantia le otorga derechos legales espe-

bnegen no regir para usted. qe modo que las limitaciones mencionadas esbecisjes' iucidentales o consecuentes, bermiten la exclusion o limitación de danos EXPRESA 0 IMPLICITA. Algunos Estados no

DE ESTA O CUALQUIER OTRA GARANTIA, O CONSECUENTE DEBIDO AL INCUMPLIMIENTO CASO POR ALGUN DANO ESPECIAL, INCIDENTAL CONAIR NO SERA RESPONSABLE EN NINGUN

meuciousqss bneqeu uo kedik baks nateq: darantia implicita, de modo que las limitaciones miten limitaciones sobre la duración de una GARANTIA ESCRITA. Algunos Estados no per-POR LOS, 12 MESES DE LA PRESENTE PROPOSITO ESPECIFICO, ESTARAN LIMITADAS DE COMERCIABILIDAD Y ANTITUD PARA UN PERO NO LIMITADAS A LA GARANTIA IMPLICITA RESPONSABILIDAD IMPLICITAS, INCLUYENDO CUALQUIERA GARANTIA, OBLIGACIÓN O

la lecha de ladricación. beuoqo qe âsısups seis qe 12 meses s partir de de envio. En ausencia del recibo de compra, el mar al 1-800-366-0937 para recibir instrucciones uecesigu qal nus blieba de compra y deben iiamanejo y envío. Los residentes de California sólo nu cuedne o diko bostsi qe 23.0002 bok dastos qe s continuacion, junto con su recibo de compra y regrese su aparato al Centro de Servicio indicado Para obtener servicio tecnico bajo esta garantia,

de materiales o tabricación. bartir de la fecha de compra si presentara defectos sbararo alu cardo bor nu periodo de 12 meses a Conair reparará o remplazará (a su opción) su

ONA NU 30 ADATIMIJ AITNARAĐ

interno despues de cada uso. remanente en el depósito y en el tanque nn desempeno optimo, saque el agua alto contenido en minerales. Para lograr Nota: El agua de la llave puede tener un

> SOLUCION: Limpie la cal CAUSA: Depósitos de sarro

PROBLEMA: El aparato produce poco vapor

ej agua baje 20F0ClON: Alce la manguera para que CAUSA: Condensación en la manguera PROBLEMA: La boquilla burbujea

ei agua paje

20FNCION: Alce la manguera para que CAUSA: Condensación en la manguera

la boquilla • PROBLEMA: Gotas de agua caen de

el depósito SOLUCION: Apague el aparato y llene CAUSA: El nivel de agua está bajo

• PROBLEMA: El aparato no produce vapor SOLUCION: Liene el depósito

CAUSA: El depósito de agua está vacio automáticamente

• PROBLEMA: El aparato se apaga

готпасотпепте

SOLUCIÓN: Conecte el cable a un CAUSA: El aparato no está enchufado PROBLEMA: El aparato no calienta

RESOLUCION DE PROBLEMAS

cou nu faudne de agua fresca. bara desarrugar prendas, repita estos pasos boquilia. Antes de voiver a usar el aparato pasta que el vapor salga normalmente de la vez una nueva mezcia de agua con vinagre, Repita estos pasos 2 o 3 veces, usando cada minutos, luego vacie el liquido remanente. el aparato. Permita que entrie durante 30 se haya evaporado. Apague y desconecte Espere hasta que la mitad del líquido (1 litro) ei deposito en la base y encienda el aparato. agua. Vierta la mezcla en el deposito. Coloque Mezcle 1/3 de vinagre blanco con 2/3 de

trecuencia de uso del aparato. qebeuqeış qe la dureza del agua y de la regularmente. La frecuencia de la limpieza recomendamos que limpie la cal Para lograr resultados optimos, le

metálicas internas del aparato. gebositos de sarro acumulados en las partes se deberá limpiar la cal, sea eliminar los mientras nay agua en ei tanque todavia, el indicador de agua baja se encendiera iuncionara de manera intermitente, o si 21 GI SDSLSTO DLOGNÎGLS MGUOS ASDOL O LIMPIEZA DE LA CAL coldar la prenda en

еј дзисио



seas o retciobeio. No permita que la boquilla haga contacto con

telas necesitan mas de una aplicacion. más fácil y rápido y usted aprenderá cual Con práctica, desarrugar prendas se volverá

cnantas veces sea necesario. riempo para desarrugarse. Aprique vapor

jejse wse gensas pueden necesitar más

toallas, servilletas y manteles colgándolos en ia prenda. Se le nara mas facil desarrugar area discreta de la tela antes de desarrugar NOTA: Haga una prueba de color en un

relaja las fibras y elimina las arrugas. mejor cuando se aplica vapor por dentro. Esto ropa con la mano. Algunos tejidos responden fuera. Para terminar, aleje la boquilla y alise la desde abajo nasta arriba, por dentro y por a la prenda, iviueva la boquilla lentamente Sostenga la boquilla con los orificios frente CONSEJOS PARA DESARRUGAR PRENDAS caliente durante el uso. Evite tocarla.

PRECAUCION: La manguera se volvera

Potentes chortos de vapor

nasta el tanque. qesabarecera cuando ei agua naya bajado a manguera completamente. El gorgoteo esto, levante la boquilla hasta extender sacion acumulada en la misma. Para corregir ezto es el resultado normal de la condenra manguera puede gorgotear durante el uso.

THATROOMI ATOM

durante el uso. No lo ponga sobre una mesa zee abarato debe permanecer en el piso

This steamer is designed to sit on the floor. Do not put on a table or chair when in use. OTHER IMPORTANT NOTES

During operation, the steamer hose may gurgle. This is a normal result of condensation collecting inside the hose. Simply lift the cool-touch handle upward until the hose is extended to its full height. The gurgling will disappear when the excess moisture inside the hose has had a chance to drain back into the base

CAUTION: Hose will be hot when in use. Avoid prolonged contact.



high velocity steam jet T-nozzle

HOW TO STEAM

Grasp the cool-touch handle with the steam iets in the nozzle facing away from you. Begin at the bottom of the fabric to allow the steam to rise inside and outside, removing wrinkles. Slowly move the nozzle from the bottom to the top of the fabric. Remove the nozzle from the garment and smooth the fabric with your free hand. Some fabrics are best steamed on the underside of the material. This will allow the fibers of the fabric to relax, eliminating wrinkles.

NOTE: Test fabric for color fastness in an inconspicuous spot. Drape linens, towels, handkerchiefs and napkins over a rod or place on a towel rack.

Heavier fabrics may require repeated steaming. Repeat as necessary.

With practice, you will gain speed and efficiency. You will soon learn which fabrics require multiple steam applications.

Do not directly touch velvet or silk with the steam head.



using the over-the-door hook

Always steam with hose in upright position, so any condensation is free to flow back into the steamer.

If you steam in a low position, condensation will collect inside the hose. This will cause gurgling and some water droplets to form near the steam jets on the T-nozzle. To avoid this, frequently lift the steam handle upward until the hose is extended to its full height.

TO STEAM DRAPES

Wash and dry drapes as directed according to fabric type. Re-hang drapes and steam drapes when in place.

CLEANING AND STORING

I. Turn the ON/OFF switch to the OFF position and unplug from the power source. 2. Wait for the steamer to cool completely for

at least 30 minutes. 3. Unplug power cord and gently wrap around

- the bottom of the unit. Remove steamer hose.
- 5. Remove excess water from the reservoir by lifting the unit and pouring down a drain.
- 6. Wrap hose around unit or remove hose from steamer housing and coil and store

DECALCIFICATION

If the appliance begins to produce steam more slowly than usual, if the steamer stops producing steam and then starts again, you may need to decalcify your steamer. Decalcification refers to removing the calcium deposits which form over time on the metal parts of the steamer. For best performance of the Conair™ Fabric Steamer, decalcify the unit from time to time. The frequency depends upon the hardness of your tap water and how often you use the steamer.

To decalcify, use a solution of 1/3 white vinegar and 2/3 water in the water container. Plug the unit into electrical outlet. Turn to the ON position and run until half the amount has steamed. Turn the unit to the OFF position, unplug from electrical outlet, and allow to sit for 30 minutes.

Remove excess water from the reservoir by lifting the unit, inverting and pouring the water over sink, and allowing water to drain from internal reservoir. Repeat the above procedure as many times as necessary until a normal steam rate returns, usually 2-3 times. With each repeated cycle, use a fresh solution of vinegar and water. Run one cycle of fresh, cold water through the unit at the completion of decalcification, before using the unit again to steam garments.

TROUBLESHOOTING THE STEAMER

- PROBLEM No steam CAUSE - Steamer not turned on SOLUTION - Turn ON/OFF switch to ON position
- . PROBLEM Steamer fails to heat CAUSE - Steamer not plugged in SOLUTION - Plug into electrical outlet
- PROBLEM No steam CAUSE - Water level is low SOLUTION - Turn ON/OFF switch off and refill water container
- PROBLEM Water drips from nozzle CAUSE - Condensation in hose SOLUTION - Hold the hose vertically and allow water to drain back into unit
- PROBLEM Nozzle gurgles CAUSE - Condensation in hose SOLUTION - Hold the hose vertically and allow water to drain back into unit
- PROBLEM Poor steam performance CAUSE - Sediment in container SOLUTION - Decalcify reservoir and water container

Note: Minerals in water will vary in different areas. To insure continued operation of the steamer, never store without cleaning and removing excess water from the reservoir and water container.

LIMITED ONE-YEAR WARRANTY

6. Enrolle la manguera alrededor de la base.

5. Vacie el agua remanente en el depósito.

2. Permita que el aparato entrie durante 30

1. Apague (OFF) y desconecte el aparato

instrucciones del fabricante. Cuelgue las

ocnira, alce la manguera frecuentemente.

escion se podria acumular adentro de la

Si la manguera no estuviera recta, conden-

para que la condensación baje hacia el

Siempre sostenga la boquilla recta y alta,

drian mojar las prendas. Para evitar que esto

podnilla, causando gorgoteo y gotas que po-

CONSEJOS PARA DESARRUGAR CORTINAS

4. Desconecte la manguera.

LIMPIEZA Y ALMACENAJE

cortinas y desarriguelas después.

Гэле у seque las cortinas segun las

minutos o más.

antes de limpiarlo.

3. Desconecte el cable y enrollelo.

Conair will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or materials. To obtain service under this warranty, return the defective product to the service center listed below that is nearest you, together with your purchase receipt and \$3.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-366-0937 for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 12 months from the date of manufacture.

ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SHALL BE LIMITED IN DURATION TO THE 12-MONTH DURATION OF THIS WRITTEN WARRANTY. Some states do not allow

limitations on how long an implied warranty lasts, so the above limitations may not apply

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED. WHATSOEVER.

Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to

Service Center Conair Corporation Service Department 7475 N. Glen Harbor Blvd. Glendale, AZ 85307

For information on any Conair products call: 1-800-3-CONAIR or visit us on the web at http://www.conair.com

©2008 Conair Corporation East Windsor, NJ 08520/Glendale, AZ 85307

compact fabric steamer

Model GS33



Instructions for Use

For your safety and continued enjoyment of this product, always read the instruction book



08PA10381